

## FLEXBAR MACHINE CORPORATION MODEL #13460

## MILLING MACHINE VISOR GUARD KIT INSTALLATION INSTRUCTIONS

Install <u>Machine Arm</u> on the horizontal area behind the motor drive head.

There are several methods of installation depending on your machine.

1. Use the 3/4", 5/8" or 19mm threaded lifting hole if available

5/8" reducer washer supplied

Tighten the 3/8" bolts 2X to stabilize the arm

This kit is set up for left side installation

For right side installation reverse flexarm to shield mount

- 2. Drill & tap 3/8" -24 holes 2X. Use the Machine Arm as a drill template
- 3. Use the 1/2" holes 2X and drill & tap custom mounting holes
- 4. For machines with a Digital Readout mounted in the lifting hole use the Readout spacer

250 GIBBS ROAD • ISLANDIA, NY 11749 800-879-7575 • FAX 631-582-8487 www.flexbar.com Install the Horizontal Tube into tube mount and lock

- 1. The tube mount can be adjusted left or right
- 2. The Horizontal Tube can be adjusted front to back
- 3. The Vertical angle should be in the vertical downward position

Install the Flexarm/Shield to the Vertical Angle

- 1. Remove the screws from the flexarm body
- 2. Install the flexarm body to the bottom of vertical angle with screws and lock washers

Adjust the vertical angle up and down and adjust the flexarm to properly position the shield

Adjust the flexarm tension so it will hold the shield in position but can easily be moved

See illustrations for details

