




INSTALLATION INSTRUCTIONS

VISORGUARD (ALL MODELS)

FLEXBAR MACHINE CORPORATION
250 GIBBS ROAD – ISLANDIA, NY 11749
800-879-7575

WWW.FLEXBAR.COM – SALES@FLEXBAR.COM



Note 1: Tighten nut until it hits stop.

ASSEMBLE WASHERS, FLEXARM AND COMPRESSION SPRING ONTO SHAFT, AS SHOWN.

TIGHTEN 1/4-20 LOCKING HEX NUT UNTIL COMPRESSION SPRING IS BOTTOMED OUT.

VISORGUARD, U.S. PATENT – 4,543,021/MANUFACTURED BY FLEXBAR MACHINE CORPORATION.